

AccuPark Interlocking Garage Floor Tiles

Installation Instructions

Instructions:

NOTE: The AccuPark™ system is designed to integrate directly with any RaceDeck® modular garage surface. This system has also been designed to work for portable applications or over any garage flooring surface with the use of our anti-slip mat feature. The components for both methods of installation have been provided in every kit and will be covered in this instruction sheet.

RaceDeck® Garage Surface Installation:

1. Mark the location(s) of the front tire(s) of the vehicle where it will be parked in the garage.
2. Begin installing RaceDeck flooring system to the pre-approved layout per most recent installation methods and procedures.
3. Install the two black floor tiles with the loops in the same direction as the RaceDeck® garage tile in the area(s) previously marked in step 1. Refer to Illustration A for detail.




Illustration A

NOTE: The AccuPark™ system will be perpendicular to the garage entrance.

4. Continue installing the RaceDeck garage surface to the pre-approved layout. If additional AccuPark™ systems are required, install the black floor tile in the same manner as previously mentioned in their appropriate locations. Wipe off the black floor tiles with a clean towel to remove any dust or debris.
5. With the RaceDeck® garage surface and black floor tile installed and cleaned, remove the protective film on the underside of the AccuPark™ diamond plate top and place squarely over the black floor tiles. Press down on the plate firmly to ensure a proper bond. Allow the adhesive to set up for at least 2 hours before use. Repeat process for any additional AccuPark™ units. Refer to Illustration B for detail.




Illustration B

Portable / Generic Garage Surface Installation:

1. Remove the protective film on the underside of the AccuPark™ diamond plate top and place squarely over the black non-slip rubber mat. Press down on the plate firmly to ensure a proper bond. Allow the adhesive to set up for at least 2 hours before use. Refer to Illustration C for detail.




Illustration C